




# SUPERLUXE

Lengths 125cm - 500cm


Read all instructions carefully before installation

## PRODUCT ASSEMBLY ILLUSTRATIONS

125cm to 275cm



300cm to 500cm




## TRACK LENGTH AND COMPONENTS

TRACK ( cm)		125	150	175	200	225	250	275	300	350	400	500
BRACKETS	A	4	4	5	5	6	6	8	8	8	10	12
LEVERS	B	4	4	5	5	6	6	8	8	8	10	12
GLIDERS	C	16	18	22	24	28	30	34	36	42	52	60
CORD TENSIONER	D	1	1	1	1	1	1	1	2	2	2	2
OVERLAP ARM	E	1	1	1	1	1	1	1	1	1	1	1
OVERLAP ARM	F	1	1	1	1	1	1	1	1	1	1	1
CENTRE JOINER	N	-	-	-	-	-	-	-	1	1	1	1

## INFORMATION FOR BAY WINDOWS

PLEASE NOTE THAT SUPERLUXE TRACK IS ONLY SUITABLE FOR INTERNAL BENDS WITH A RADIUS OF 25cm OR MORE. WITH THE FRONT OF THE TRACK FACING YOU, BEND THE ENDS TOWARDS YOURSELF.


## WARNING



- Young children can STRANGLE in the loop of pull cords, chains and tapes that operate window coverings
- To avoid strangulation and entanglement, keep cords out of the reach of young children.
- A cord tensioner is supplied to help minimise the risk of injury.
- Move beds, cots and furniture away from window covering cords.


PERSONS IN CHARGE OF CHILDREN ARE ULTIMATELY RESPONSIBLE FOR FOLLOWING THE SAFETY INSTRUCTIONS PROVIDED BY THE MANUFACTURER AND TO USE ANY SAFETY DEVICE SUPPLIED.

## 1. TOOLS REQUIRED



A general fitting pack is included but when fixing to dry line, masonry or studed walls ensure the correct fixings are used. If you are unsure please seek advice.


## 2. BRACKET SPACING




Decide where the track is to be fixed. Measure and mark the bracket positions using a spirit level and measure. NOTE: the end bracket should be positioned 2cm (3/4") in from the end of the finished length of your track. Mark equally spaced positions for all remaining brackets.

## STRAIGHT RUNS - 300cm to 500cm

Follow steps above but ensure bracket positions are marked 4cm either side of the centre. This allows for the track joiner and return pulley to be positioned correctly and gives maximum support when brackets are locked into position, as shown in fig. 2.




(Ensure all remaining brackets are equally spaced between those shown with specific distances from corners). Additional fixing brackets are sold separately if required from your local Swish stockist - part number WD310W005K.



### 3. BRACKET FIXING

Secure all brackets A into position with the Swish logo facing upwards. Now install lever B into every bracket and leave in a vertical position



### 4. SHORTENING THE TRACK

125cm to 275cm - Cut from one end only

Using your finished track length calculated in section 2, mark a line equal to this length onto the track.


Subtract a further 4.5cm from this and draw a line. This is now your CUT line. This takes into account pulley housing (K2) when the rail is reassembled after cutting.

Pull outer cord (J) to move master carriers (G & H) to the centre of the track (closed position).

Slacken screw (X) and slide off pulley housing (K2). Move cords away from section of track to be cut off taking care not to twist the cords.


Carefully cut square using a hacksaw and smooth off cut edges.

Replace pulley housing (K2) taking care not to twist the cords and tighten screw (X) to secure.



TO RECENTRALISE THE MASTER CARRIERS - (G & H)

Pull outer cord (J) until looped carrier (H) is tight against gliders (C).



Ease the cord loop out of master carrier (H) (this will reduce the length of the pull cord) and (2) pull inner cord loop until knotted carrier (G) is tight against gliders (C)(3).

Pull outer cord pull (J) to reduce the excess cord on the looped master carrier (H) and resecure loop (4).

NOTE: If knotted master carrier (G) reaches gliders first pull out loop from looped master carrier (H) and move carrier (H) through loop until it reaches gliders Pull outer cord pull to reduce excess loop on looped master carrier (H) and resecure.

300cm to 500cm - Cut from each end

Using your finished track length calculated in section 2, divide this distance by 2 and subtract a further 4.5cm.

Measuring from the centre, mark a line on each section of track equal to this newly calculated length This is now your CUT line and takes into account pulley housings (K1 & K2) when the rail is reassembled after cutting.

Carriers (G & H) are operated individually by using pull cords (J) at each end.


Pull outer cord (J) to move master carriers (G & H) to the centre of the track (closed position).

Slacken screw (X) and slide off pulley housing (K1 & K2). Move cords away from section of track to be cut off taking care not to twist the cords.

Carefully cut square using a hacksaw and smooth off cut edges.

Replace pulley housings (K1 & K2) taking care not to twist the cords and tighten screw (X) to secure.


NOTE: If your cord pull requires shortening see section 5.



### 5. SHORTENING THE PULL CORD

Pull outer cord to curtains open position.

Take inner most cord (J) from master carrier (G) and pull until the required amount of pull cord is left hanging from pulley housings (K).




Knot cord in master carrier (G) and cut off excess cord.

### 6. CONVERT PULL CORD TO OPPOSITE END

125cm to 275cm ONLY

Pull cord to bring the two master carriers (G & H) to the centre of the track. Pull the outer cord on the looped carrier (H) so that the cord loop disappears into the pulley housing (K2).

Release screw (X) and remove rear cover from opposite pulley housing (K1). Pull the outer cord so the loop in master carrier (H) is pulled through the pulley housing (K1). Secure loop to carrier as shown.



### 7. CONVERTING TO ONE WAY DRAW

125cm to 275cm ONLY


Detach cord loop from master carrier (H). Pull outer cord so that cord loop is pulled into the track.

Loosen screw (X) and remove pulley housing (K2).

Remove gliders (C) and master carrier (H).

Add or remove gliders (C) as required to achieve one way draw direction.

Replace pulley housing (K2), ensuring cords are not twisted and tighten screw (X) to secure.



### 8. ASSEMBLY & INSTALLATION

125cm to 275cm ONLY


Starting at one end offer the upper channel of track up to fixing bracket (A) and secure by rotating Lever (B) through 90° to a horizontal position.

300cm to 500cm ONLY


Lay track face down onto a flat surface. Slide centre joiner (N) halfway into track ends and tighten screws. Repeat for centre return pulley (M).

Starting at the centre offer the upper channel of track up to fixing bracket (A) and secure by rotating Lever (B) through 90° to a horizontal position.

When installing longer lengths assistance may be required to support the rail at the other end.





ALL SIZES (125 - 500cm)



Overlap arm (F) and Underlap arm (E) can be easily located into either carrier (G & H). These can be easily altered depending on the light direction.

Attach cord tensioning device (D) to cord (J) as shown below. Once the rail is secured to fixing brackets (A) the tensioning device can then be secured to the wall or skirting board. Be sure to apply tension to the cord before fixing.



### 9. HANGING YOUR CURTAINS

Insert Swish WN800 curtain hooks into curtain tape. Allow one hook for each pulley housing and two for each master carrier i.e. total hooks required = no. of gliders + 6.

Lift curtain up to track and support curtain weight while attaching first two header tape hooks to the master carrier and, working outwards, hooking header tape hooks into gliders Attach final hook to the pulley housing. Repeat for opposite side.

